


# Installation Guide (LTR-450C)


LTR-450C

## Warning

Caution with main supply and live wires. Install with qualified technician or trained personnel. It is highly recommended to connect the ESC Earth wire to prevent power surge from damaging this device.



## Methods of Mounting




Wedge Anchor  
M8 x 48(L) x 4 Nos.

Ceiling Suspension

# Installation Guide (LTR-450C)

LTR-450C




# Installation Guide (LTR-450C)

LTR-450C

## Pairing, Limit Position Settings, and Deleting

### Pairing RF Remote to Electronic Motor



Step 1 : Switch off and on Main Power (Motor will beep).


Step 2 : Press setting button (**P2**) one time for 5 seconds (Motor will roll up and down).

Step 3 : Press setting button (**P2**) one more time for 5 seconds (Motor will roll up and down).

Step 4 : Press (**Up**) button one time (Motor will beep and roll up and down).

Step 5 : Done.

## RF Remote Operation



- Press (**Up**) button to move upwards.
- Press (**Stop**) button to Stop movement.
- Press (**Down**) button to move downwards.
- Press and Hold (**Stop**) button for 2 seconds to move to the third limit (**For maintenance purposes**).

**End**